



Parameter Dimensions

[unit: mm]

		Swiss-Turn	Blank Milling
Abutment	A	≥ 0.5	
	B	≥ 3°	
	C	≥ 1.1	
Crown	D	0.65	
	E	0.05	0.06
	F	0.02	0.03
	G	0.5*	

*Dist. to margin line may vary depending on shoulder width

Vertical Retention Groove Placement



When using a vertical retention groove, use a hole with diameter 2.0mm or greater. Make sure the vertical retention groove is placed such that the crown will be properly aligned.